

TABLE OF CONTENTS

FOREWORD	iii
LAGGING TASK FORCE	iv
NOTICE TO USERS OF THIS PUBLICATION	v
TABLE OF CONTENTS	vii
CHAPTER 1 INTRODUCTION	
1.1 INTRODUCTION	1.1
1.2 SCOPE	1.1
1.3 USES	1.1
1.4 TERMS AND DEFINITIONS	1.1
1.5 PURPOSE	1.1
1.6 OVERVIEW	1.2
1.7 COMMON LAGGING MATERIALS	1.2
CHAPTER 2 MATERIALS	
2.1 ENVIRONMENTAL CONSIDERATIONS	2.1
2.2 LAGGING SUPPORT SYSTEMS (STRUCTURAL)	2.2
2.3 EXPANSION AND CONTRACTION	2.15
2.4 JOINT & EDGE SEALING	2.15
2.5 NOISE AND SOUND CONTROL	2.15
2.6 FLAT SHEET VS. BOX RIB	2.18
2.7 WEIGHT	2.20
CHAPTER 3 ACCEPTED INDUSTRY PRACTICES FOR SHEET METAL LAGGING	
3.1 INTRODUCTION	3.1
3.2 GENERAL APPLICATION TECHNIQUES	3.1
3.3 LEGEND	3.2
3.4 LOCKS AND SEAMS	3.4
3.5 TANKS (SHELLS AND HEADS)	3.7
3.6 ROUND AND RECTANGULAR FLUE AND DUCT	3.11
3.7 PENETRATIONS	3.20
3.8 JOINTS AND SEALS	3.23
3.9 FLASHING	3.28
3.10 DOORS AND OPENINGS	3.41
3.11 PRE-INSULATED LAGGING PANELS	3.49
3.12 BUCKSTAYS	3.52
3.13 SPECIALTIES	3.57



CHAPTER 4	GUIDE SPECIFICATION	
4.1	INTRODUCTION	4.1
4.2	DRAWINGS	4.1
4.3	SEISMIC RESTRAINT PROVISIONS	4.1
4.4	GUIDE SPECIFICATION	4.1
GLOSSARY		G.1
INDEX		I.1



TABLES

1-1 Galvanized Steel Gages, Thickness and Weights	1.3
1-2 Stainless Steel Gages, Thickness and Weights	1.4
1-3 Aluminum Thickness and Weights	1.6
2-1 Typical Wind Loading vs. Support Spacing for Sheet Metal Lagging	2.12
2-2 Area Weight of Lagging	2.20



FIGURES

2-1 Example of an H-Bar System	2.3
2-2 Example of a Z-Bar System	2.4
2-3 Example of a Stud and Drive Plate System	2.5
2-4 Example of a Pin and Sub-Girt System	2.7
2-5 Single Span Lagging Support	2.9
2-6 Double Span Lagging Support	2.11
2-7 "Hat Bar" or "Hat Channel" Sub-Girt	2.13
2-8 Typical Sheet Metal Screw	2.14
2-9 Acoustical Insulation and Lagging System	2.17
2-10 Types of Ribbed Lagging	2.19
3-1 Legend	3.3
3-2 Locks and Seams	3.5
3-3 Tank (Shell & Head)	3.8
3-4 Tank Head	3.9
3-5 Round Duct	3.12
3-6 Rectangular Duct	3.13
3-7 Round Tee	3.14
3-8 Round Tee (continued)	3.15
3-9 Round Elbow	3.16
3-10 Round Elbow (continued)	3.17
3-11 Square to Round Transition	3.18
3-12 Square to Round Transition (continued)	3.19
3-13 Penetration with Horizontal Movement	3.21
3-14 Boxed Opening	3.22
3-15 Lap and Butt Joints	3.24
3-16 Expansion Joint, Non-Metallic	3.25
3-17 Fabric Expansion Joint	3.26
3-18 Weatherproof Metal Expansion Joint	3.27
3-19 Corner Closure on Rectangular Surface	3.29
3-20 Corner Closure on Curved Surface	3.30
3-21 Corner Construction	3.31
3-22 Vertical Inside Corner Construction	3.32
3-23 Corner Construction at Horizontal Overlap	3.33
3-24 Corner Construction at Vertical Outside	3.34
3-25 Corner Construction at Vertical Inside	3.35
3-26 Horizontal to Vertical Inside Corner	3.36
3-27 Vertical Outside Corner	3.37
3-28 Drip Detail	3.38
3-29 Flashing at Slope	3.39

FIGURES (continued)

3-30 Flashing at Stiffener	3.40
3-31 Sootblower and Small Pipe Protrusions	3.42
3-32 Test Port	3.43
3-33 Access Door	3.44
3-34 Covered Access Door	3.45
3-35 Header Box	3.46
3-36 Louver	3.47
3-37 Access Door In Lagging	3.48
3-38 Pre-Insulated Panel System	3.50
3-39 Sloped Top Surface and Vertical Pre-Insulated Lagging Panels	3.51
3-40 Lagging Construction Over Buckstays	3.53
3-41 Plan View at Corners of Buckstays	3.54
3-42 Vertical Buckstay with Lagging Cover	3.55
3-43 Horizontal Buckstay with Lagging Cover	3.56
3-44 Lagging at Hopper	3.58
3-45 Hopper Outlet Flange Detail	3.59

